SW38-SW49

Illuminated and non-illuminated Buttons, latching and momentary

1. Identify the style of connector on your button in the images below.

12mm



Part Numbers:

KICSWBM12X,
SW45

16mm



Part Numbers:

KICSWBL16**, KICSWBM16**,
SW38*, SW39*

19mm



Part Numbers:

KICSWBL19**, KICSWBM19**,
SW42*, SW43*,

KICSWBL19X, KICSWBM19X
(no illumination)

22mm



Part Numbers:

KICSWBL22**, KICSWBM22**,
SW46*, SW47*

2. Use 'Normally Open' connections to close circuit when button is pressed. Use 'Normally Closed' connections to open circuit when button is pressed.

3. Optionally, L.E.D. can be wired to illuminated upon button activation. Use the button itself to control L.E.D. See button illumination wiring diagram on page 2.

BilletButtons™ hole sizes template:



©2012 The Hoffman Group All rights reserved. Billet Buttons Instructions_NEW Rev1.1 05/18/12 Page 1 of 4.

The above instructions are for reference only. THG is not responsible for any inaccuracies in the above instructions. THG is also not responsible for any property damage or personal injuries resulting from the above instructions. Installation by qualified automotive professionals is highly recommended.

Billet Buttons

Button Illumination Wiring

Illumination Always On



Illumination On With Ignition



Illumination On When Pushed



Application Wiring

Controlling Motors

Power Windows, Sunroof, Linear Actuators, Door Locks



Motor Control Units

Air Command, Window Control



Solenoid Control

Power Trunk, Shaved Door, Power Bear Claw



Turn Signals & Hazards



©2012 The Hoffman Group All rights reserved. Billet Buttons Instructions_NEW Rev1.1 05/18/12 Page 2 of 4.

The above instructions are for reference only. THG is not responsible for any inaccuracies in the above instructions. THG is also not responsible for any property damage or personal injuries resulting from the above instructions. Installation by qualified automotive professionals is highly recommended.

Billet Buttons

Engine Start



Note: Put key in ignition to unlock column and turn on accessory.

Headlights



Cooling Fan



Starter Kill



Airbags



Battery Kill



©2012 The Hoffman Group All rights reserved. Billet Buttons Instructions_NEW Rev1.1 05/18/12 Page 3 of 4.

The above instructions are for reference only. THG is not responsible for any inaccuracies in the above instructions. THG is also not responsible for any property damage or personal injuries resulting from the above instructions. Installation by qualified automotive professionals is highly recommended.

Two Button Push Start



Backup System Override

Negative System



Positive System



*Some of our Billet Buttons have multiple color options. If you wire up your LED and it is the incorrect color, exchange the LED + and LED -, and the color will change.

©2012 The Hoffman Group All rights reserved. Billet Buttons Instructions_NEW Rev1.1 05/18/12 Page 4 of 4.

The above instructions are for reference only. THG is not responsible for any inaccuracies in the above instructions. THG is also not responsible for any property damage or personal injuries resulting from the above instructions. Installation by qualified automotive professionals is highly recommended.